

TRIUMPH SPRINT ST 2005-2009 DIY WINDSCREEN INSTALL

**PLEASE READ BEFORE MOUNTING YOUR WINDSCREEN**

**Installation Manual for Triumph Sprint ST 2005-2009 Windscreen Install**

Thank you for purchasing one of Zero Gravity's windscreen, which has been designed and manufactured to give years of safe & fun riding. This instruction manual gives you an in-depth look at the install process. To receive further assistance or parts please call Zero Gravity® Sales Department at 805-388-8803 or E-mail at [salesinfo@zero-gravity-racing.com](mailto:salesinfo@zero-gravity-racing.com).

**Helpful hints:** Use metric tools, clean hands, put the bike on a center stand. Do not pry on the screen excessively, as it will break without much warning.

**NOTE:** Included with your Sprint ST windscreen are 6 stainless steel screws and 4 rubber "Well Nuts". These Well Nuts (from Part# No.32-140) are similar to the two rubber inserts that your stock windscreen fastens to at the rear of the screen. Your stock windscreen uses 4 tabs, molded into the forward half of the screen, that insert into four slots in your fairing. In addition, two screws fasten the rear half of the screen to the fairing.



Your Zero Gravity windscreen does not use the four mounting tabs. Instead, it incorporates 6 mounting holes and is mounted to your fairing using the included Well Nuts and Stainless Steel Screws.

**Mounting Your Zero Gravity Windscreen**

**Step One:** First remove your existing windscreen from the fairing by unscrewing the two screws at the rear of the windscreen and pulling upward and rearward on the screen to pull it out of the mounting slots.

**Step Two:** Insert the four Well Nuts in the existing 4 holes in your fairing that correspond to the position of the mounting holes in your Zero Gravity windscreen.

**Step Three:** Position your Zero Gravity windscreen in its place on the fairing and then insert the screws included with your windscreen into the mounting holes. Thread the screws into the Well Nuts initially just enough to keep them in place. When all 6 mounting screws are in place, tighten each screw starting with the screws closest to the headlight working your way rearward. Tighten the screws enough to cause sufficient expansion of the Well Nut to keep the windscreen snug to the fairing.

**DO NOT OVER-TIGHTEN!**

Insert the 4 included Well Nuts (Part# 32-910 made just for 910) in the 4 existing holes in your fairing before installing your new Zero Gravity Windscreen

